

ROAD EQUIPMENT > VARIO TRAFFIC SIGN

## Assembly VARIO angled delineator cap

1. Put the base on the support post/round post and press down as far as it will go. (Fig. 1)
2. Put the film carrier on the base: push in the first mount, align the sign, push in the second mount and then press down as far as it will go. Repeat this process with the second film carrier. (Fig. 2)
3. Attach the connecting brace and press down as far as it will go. (Fig. 3)



**Fig. 1**  
**Base**



**Fig. 2**  
**Film carrier**



**Fig. 3**  
**Brace**

4. Fix the VARIO angled delineator cap with 4 screws:
  - a) Foil carrier: 1 x each on the upper mount (connects foil carrier with strut and base part)
  - b) Base part: 2 x in the middle ring in the area of the radii of the support post

